
\*The last four digits will not appear on your billing statement because we read to the 100<sup>th</sup>.



Sensus Meter- If you have a possible leak then the numbers after the decimal will be moving. Please allow 5 seconds for movement. If numbers do not appear, you may have to open & close the gray case to wake the meter up.


\*Be sure that no one is using water inside the house when checking meter.



Neptune Meter- If you have a possible leak two things will occur 1.) An image of a faucet will appear on the display. 2.) The numbers after the decimal will be moving. Please allow 5 seconds for movement. If numbers do not appear, shine a bright flash light on the face of the meter and digits will appear.

\*Be sure that no one is using water inside the house when checking meter.

Unlike the meters above the reading for our master meters as seen below would be 5911.



**Master Meter-** If you have a leak, the wheel in the middle of the meter will be turning.

\*Be sure that no one is using any water inside the house when checking meter.